

## Bussole con Inserti a Brugola Sockets for inhex screw



Modello Model	Attacco Drive	
	mm	
940.4	4	1/2"
940.5	5	1/2"
940.6	6	1/2"
940.8	8	1/2"
940.10	10	1/2"
940.12	12	1/2"

## Porta Inserti Bits Holder



Modello Model	Attacco Drive	
909.1/4	1/4"	1/4"
909.3/8	3/8"	1/4"
909.1	3/8"	5/16"
909.2	1/2"	5/16"

## Inserti Bits



Modello Model	Attacco Drive	
	mm	
909.1/4.3	3	1/4"
909.1/4.4	4	1/4"
909.1/4.5	5	1/4"
909.1/4.6	6	1/4"
909.1/4.8	8	1/4"
909.1/4.10	10	1/4"

Modello Model	Attacco Drive	
	mm	
909.3	3	5/16"
909.4	4	5/16"
909.5	5	5/16"
909.6	6	5/16"
909.8	8	5/16"
909.10	10	5/16"

## Adattatori Adapters



Modello Model	Ingresso Input	Uscita Output	Note
970.1	1/4" F	3/8" M	Quadro/Square-Quadro/Square
970.2	3/8" F	1/4" M	Quadro/Square-Quadro/Square
970.3	3/8" F	1/2" M	Quadro/Square-Quadro/Square
970.4	1/2" F	3/8" M	Quadro/Square-Quadro/Square
970.5	1/2" F	3/4" M	Quadro/Square-Quadro/Square
970.6	3/4" F	1/2" M	Quadro/Square-Quadro/Square
970.7	9x12 M	14x18 F	Attacco/Drive
970.8	14x18 M	9x12 F	Attacco/Drive
970.9	1" F	3/4" M	Quadro/Square-Quadro/Square
970.10	9x12 M	1/2" M	Attacco/Drive - Quadro/Square
970.11	14x18 M	1/2" M	Attacco/Drive - Quadro/Square
970.12	14x18 M	1/4" F	Attacco/Drive - Esagono/Hex
970.15	22x28 M	14x18 F	Attacco/Drive

## Bussole con esagono femmina Sockets



Modello Model	Attacco Drive	
	mm	
907.8	8	3/8"
907.9	9	3/8"
907.10	10	3/8"
907.11	11	3/8"
907.12	12	3/8"
907.13	13	3/8"
907.14	14	3/8"
907.15	15	3/8"
907.16	16	3/8"
907.17	17	3/8"
907.18	18	3/8"

Modello Model	Attacco Drive	
	mm	
908.10	10	1/2"
908.11	11	1/2"
908.12	12	1/2"
908.13	13	1/2"
908.14	14	1/2"
908.15	15	1/2"
908.16	16	1/2"
908.17	17	1/2"
908.18	18	1/2"
908.19	19	1/2"
908.20	20	1/2"

Modello Model	Attacco Drive	
	mm	
908.21	21	1/2"
908.22	22	1/2"
908.23	23	1/2"
908.24	24	1/2"
908.25	25	1/2"
908.26	26	1/2"
908.27	27	1/2"
908.28	28	1/2"
908.29	29	1/2"
908.30	30	1/2"
908.32	32	1/2"